

IGNITION SHIELD KIT

PART NO. GMS 102

AUSTON/WORKS

Mini Mk I and II - Saloon, Countryman, Van and Pick-up. All Cooper and Cooper 'S' models (except when all cooler is fitted) Mini 850 and Mini 1000

LIST OF CONTENTS

PART NO	DESCRIPTION	NO. OFF
24A 3341	Ignition Shield	1
C2H 1953	Bonnet Sealing Strip	1
PWZ 804	Screw (No B Self Tapping)	3
PWZ 103	Washer	3

NB All above parts are obtainable separately for replacement purposes.

FITTING INSTRUCTIONS

- 1 Place ignition shield, 24A 3341, behind the grille panel from inside the engine compartment, ensuring that the top edge of the shield matches the shape of the top rear edge of the bonnet locking platform.
- 2 The ignition shield is mounted with the recess, C, towards the bonnet release lever.
- 3 Using the shield as a template drill three holes .128" diameter (No 30 drill size) checking that the lower fixing hole comes in the centre of the grille panel stay on the Saloons and in the centre of the 3" wide flange of the grille panel angle on the Van and Pick-up. Section B-B on illustration.
- 3 Secure the shield with the three PWZ 804 self-tapping screws and PWZ 103 washers.
- 4 Remove and discard the rubber bonnet buffers and fit the bonnet sealing strip, C2H 1953, to the flange along the forward edge of the bonnet, as shown by section A-A in illustration.

